

记录仪产品说明书

一、产品规格说明

DDR	内置64M
FLASH	8M SPI norflash
显示屏	IPS高清屏
外置端口	MINI USB 5V/2A电源接口 最大支持64G Class10 TF卡 2.5mm 三节数字后录摄像头接口
扬声器	8欧1瓦声道15*10mm扬声器
MIC	4015标准全指向麦克风
功能特性：	
前置摄像头	6玻/F2.0光圈
GPS轨迹	不支持
AV OUT	不支持
后视摄像头	6米线长/2.5mm接口
拍照	支持
镜头旋转	支持手动调整
动态范围调节	支持
HDR	支持
倒车全屏	支持
视频格式	AVI
图片格式	JPG
存储压缩方式	H.264
电池类型	150mAh聚合物锂电池
语言支持	支持多国语言
重力感应	支持

移动侦测	支持
延时关机	支持
循环录像	支持不覆盖
录音功能	支持
夜视补光灯	支持(手动开启)
停车监控	支持
前摄像头视频画质	1920x1080P
车内摄像头画质	HD1280x720
拍照分辨率	最高支持3M
工作环境：	
操作温度	-40℃~70℃
操作湿度	15-65%RH
存储温度	-40℃~70℃

二、按键功能介绍(图片仅供参考，以实物为主)

- | | |
|----------------|-----------|
| 1) 电源键, 短按息屏 | 2) 菜单键 |
| 3) 确认键 OK键 | 4) 上翻键 |
| 5) 下翻键 | 6) 显示屏 |
| 7) 车内摄像头 | 8) 夜视灯 |
| 9) 支架卡口 | 10) 复位键 |
| 11) 电源接口 | 12) TF卡槽 |
| 13) 后视摄像头 (可选) | 14) 车前摄像头 |

录像时长按【M】进入菜单设置，具体项目如下：

记录仪录像菜单			
1	分辨率	1080P FHD/720P	
2	循环录影	关/1分钟/2分钟/3分钟/5分钟	
3	曝光补偿	-3、-2、-1、0、1、2、3	
4	移动检测	开关	待机状态下有物体移动会自动开机录制
5	录影音频	开关	打开或关闭同步录音
6	日期标签	开/关	
7	重力感应	关/2G/4G/8G	剧烈晃动或碰撞后，视频自动保存并不能被覆盖
8	停车监控	关/开	无人值守监控录像
9	日期/时间	调整年/月/日/时/分/秒	
10	自动关机	关/1分钟/3分钟	
11	按键声音	关/开	
12	语言设置	简体中文等多国语言	选择语音
13	光源频率	50HZ/60HZ	光源频率选择
14	格式化	确认/取消	格式化TF卡
15	屏幕保护	关/3分钟/5分钟/10分钟	
16	默认设置	确认/取消	
17	版本	机器软件版本号	

拍照模式下长按【M】进入拍照菜单设置，具体项目如下：

1	拍摄方式	单拍/2秒定时/5秒定时/10秒定时
2	分辨率	2M/3M/5M/8M/10M/12M
3	连拍	开/关
4	图像质量	优质/标准/经济

5	锐度	强烈/标准/柔和
6	白平衡	自动/日光/阴天/钨丝灯/荧光灯
7	ISO	自动/100/200
8	曝光补偿	-3、-2、-1、0、1、2、3
9	日期标签	关/日期时间

【O】为开关电源键，短按息屏。

【M】为菜单，长按查看文件，长按进入拍照界面按确认键拍照。

【▲】为上翻键，短按打开/关夜视灯。

【▼】为下翻键，短按切换镜头界面。

OK为确认键，进入菜单OK键。

【OK】为确认键，菜单界面短按为确认，录像界面短按为录像开启/停止切换功能。

后视摄像头介绍（若有此配置）：

在录像状态下，后视摄像头4节插头插入AVIN孔，屏幕会有一小块区域显示为后视画面，表示已识别后视摄像头。短按【OK】暂停录像后，长按【▼】可以在车前摄像头、后视摄像头两种显示画面之间切换。当使用倒挡时，自动全屏显示后视摄像头画面。

安装说明

- 请先测试好后视摄像头正常后再进行安装（若有后视摄像头，没有的可忽略）。
- 关闭汽车发动机。
- 将TF卡插入记录仪卡槽中。
【注意】请使用高速TF卡（Class10以上），容量不小于4GB，TF卡最大支持64GB。
- 将记录仪通过支架固定于汽车前挡风玻璃上。
- 将车载充电器插入汽车点烟器中。
【注意】布线时可延长线沿汽车门框边缘和车内地毯下铺设。

一、Product Specification

DDR	Built-in 64M
FLASH	8M SPI norflash
Display Screen	IPS HD screen
External port	MINI USB 5V/2A power adapter port Max support 64G Class10 TF card 2.5mm digital 720P rear view lens port
Speaker	Monophonic 15*10mm speaker
MIC	4015 Standard Omnidirectional Microphone
Features：	
Front camera	6-glass/F2.0 aperture
GPS tracker	NO
AV OUT	NO
Rear camera	6M cable/2.5mm port
Photo	Support
Lens rotates	Adjust manually
WDR	Support
HDR	Support
Reversing visual	Support
Video format	AVI
Image format	JPG
Compression format	H.264
Battery	150mAh polymer lithium battery
Language	support multi-language
G-sensor	Support

Motion Detection	Support
Delay shutdown	Support
Loop recording	Support, Do not leak seconds
Sound record	Support
Fill light for night vision	Support(Open manually)
Parking monitoring	Support
Front camera	1920x1080P
In-car camera resolution	HD1280x720
Camera resolution	Max support 3M
Working Environment	
Operating temperature	-40℃~70℃
Operating humidity	15-65%RH
Storage temperature	-40℃~70℃

二、Key Features (picture for reference only, mainly in kind)

- | | |
|-------------------------------------------------|------------------------|
| 1) Power button, short press to stop the screen | 2) Menu keys |
| 3) Confirm key OK key | 4) For the flip up key |
| 5) Flip down key | 6) Display screen |
| 7) In car camera | 8) Night vision lamp |
| 9) Bracket clamp | 10) Reset key |
| 11) Power interface | 12) TF card slot |
| 13) Rear view camera (optional) | 14) Front camera |

In video mode ,long press 【M】 to enter video menu settings as follows:

Recorder Menu			
1	Resolution	1080P FHD/720P	
2	Loop recording	Off/1minutes/2minutes/3minutes/5minutes	
3	Exposure compensation	-3、-2、-1、0、1、2、3	
4	Movement detection	on/off	In standby mode, it will automatically record while a objective moves
5	Sound record	on/off	Turn on/off sound record
6	Time stamp	on/off	
7	G-sensor	Off/2G/4G/8G	When car occur collision/accident, it will lock current video and can't be covered
8	Parking monitor	on/off	unattended surveillance
9	Date/time	Adjustment Years months date/hours Minutes seconds	
10	Automatic shut-down	Off/1minutes/3minutes	
11	keypad tone	on/off	
12	OSD language	Support multilingual	Choose a language
13	Light source frequency	50HZ/60HZ	Choose the Light source frequency
14	format	Confirm/ cancel	format TF card
15	Screen saver	Off/3minutes/5minutes / 10minutes	
16	Default setting	Confirm/ cancel	
17	version	Machine software version number	

In photo mode ,long press 【M】 to enter photo menu settings as follows:

1	Shooting method	Single shooting/2 seconds timer / 5 seconds timer / 10 seconds timer
2	Resolution	2M/3M/5M/8M/10M/12M
3	Continuous shooting	on/off
4	Picture quality	High quality/standard/economy

5	Acutance	Strong/standard/soft
6	White balance	Automatic/sunlight/cloudy/tungsten lamp/fluorescent lamp
7	ISO	Automatic/100/200
8	Exposure compensation	-3、-2、-1、0、1、2、3
9	Time stamp	Off/ Dale

【O】 Press the power button to turn on and off the device, and briefly press to stop the screen.
【M】 For the menu, long press to view the file, long press to enter the photo interface, and press the confirm button to take a photo.

【▲】 Press and hold the up button to turn on/off the night vision lights.

【▼】 is the scroll down button, short press to switch the lens interface.

OK is the confirmation key, enter the menu with the OK key.

【OK】 Confirm button, short press to confirm in the menu interface , short press to video record on/off in the video mode
Rear view lens (optional)
In case of video recording , 4 pin plug of rear view lens insert AV-in hole of device, there's a rear view image in top-right of the screen, that means connected successfully; short press OK button to pause, long press 【▼】button to switch front-rear view image, when hang up "R" gear, it will show full image of rear view

Note: This device can only support dual cameras to video record at the same time (instead of 3 channels camera, that is front-inside camera or front-rear camera; if installed a rearview camera and choose front-inside view mode, it will automatically indicate full image of car reversing visual when you hang up "R" gear, but won't effect front-inside video record, also will automatically switch back front-inside view after cancel "R" gear.
As for system update to support 3 channels camera to video record at the same time, please prevail in kind and we're sorry for no further notice.

Reset key【RESET】
If the recorder crashes and accidental operation is not a normal fault, press 【RESET】 to shutdown the device, then press 【OK】 to reboot the device.

Installation Notes

- Please test the rear view camera firstly, if it works well then install (package without rear view lens can be ignored).
- Turn off the car engine.
- The TF card insert the recorder slot.
【Note】 Please use the high-speed TF card (Class10 above), capacity of not less than 4GB. TF card maximum support 64GB.
4. The recorder via a bracket fixed to the front windshield of the car.
5. Insert the car charger into the car cigarette lighter.
【Note】 When wiring, extend the charging line along the edge of the car door frame and carpet under the car laying.

6.将后置摄像头安装在车辆后部，安装时注意上下方向。布线可沿车辆顶棚边缘埋线铺设。

1.【注意】后置摄像头有两种安装方法：

- 吸附于汽车后玻璃上方，可自行动手安装（无法实现倒车可视功能，只能实时录制车后方视频）；
- 找专业安装人员安装于车牌架上方，同时摄像头需要连接倒车灯电源（可实现倒车可视功能）。

2.调整镜头位置，确保最佳拍摄视角。

3.发动引擎，检查机器是否正常工作。

功能介绍

1.使用自动记录功能

启动汽车发动机，记录仪自动启动并开启记录功能。
关闭汽车发动机，记录仪自动保存记录内容并关机，记录的影像分段保存于TF卡上，当TF卡存满后，记录仪将优先覆盖最早录制的影像。

【注意】

- 记录的时间段可自行在菜单中设置，范围为关闭和1/2/3分钟4档。
- 记录仪录像分别保存于TF卡内DCIMA与DCIMB文件夹中（若有车内摄像头或者后视摄像头）。

2.使用拍照功能

在开机状态下，短按【OK】键停止录像，短按【M】进入拍照模式，短按OK键即可拍照，如需切换回录像模式，短按几次【M】键即可。

3.使用移动侦测功能（运动检测）

机器进入录像状态，录像30秒后系统停止录像。如需退出移动侦测模式，菜单界面关闭运动检测功能。

4.重力感应功能

本车内置重力感应器(G-sensor)，如果发生严重车辆碰撞，记录仪会锁定事故发生时的前5秒和后10秒的影像资料，同时显示屏上方显示锁的图标；被锁定的影像会另存为一个特殊文件，这个文件不会被覆盖。

【提示】重力感应器(G-sensor)支持灵敏度调节，可根据实际需要在设置菜单中自行更改设置。

5.一键锁定功能

本机具备一键锁定功能，可将需要保留的影像锁定而不会被循环覆盖。在录像模式中，短按【M】键记录仪会将当前整段的视频影像锁定。

6.日期及时间设定

录像时长按【M】键进入菜单设置，找到日期/时间菜单，短按OK键进入，设置正确后再按【OK】键保存，最后短按【M】键退出菜单设置。

【注意】为了有效记录和取证，在使用本机前请立即设置正确的日期和时间。

7.文件回放

回放模式下短按【OK】键回放。如需退出回放模式，再次短按【M】键。

8.倒车可视功能（后视摄像头为可选配件）

首先，必须车充连接好记录仪，拉线摄像头黑红线连接倒车灯。插车充线路会自动启动录像状态，在录像模式下切换R档屏幕自动切换到后视镜头，显示倒车影像。结束倒车后可视后机器自动返回录像模式。
提醒：请先测试好后视摄像头正常后再进行安装。

9.停车监控模式（实现无人值守监控录像）

实现这个功能必须在本机连接常电的情况下，在主菜单中打开运动检测和停车监控功能，在待机状态下车辆受到震动或者前方有物体移动时，记录仪可根据重力感应模块G-SENSOR来感应，自动启动机器并自动锁定录像30秒，且自动保存录像文件

常见问题	
车子出现“档案错误”的提示	设置菜单->恢复出厂设置并格式化内存卡，一般是TF卡的问题
画面出现横纹干扰	请选择正确的供电频率50HZ(PAL)
如何正确开启24小时停车监控功能	正常行驶时，请不要开启，容易造成自动关机或死机 停车后才需要开启，请长按降压线或移动电源 记录仪拍摄依赖于外界较强的光源（比如路灯车灯），行业亦是如此
夜间拍摄的画面不够清晰	关机的情况下先充满电，可以用车充或者移动电源补充电量
机器总是恢复到默认日期和时间	（请关闭移动侦测功能/打开循环录像功能）自行配卡的一定选用正品C10高速卡。
录像文件出现马赛克，是什么原因	请先关闭停车监控功能/使用环境的温度超过70℃也会造成自动关机
为何录制过程中，机器一下子自动关机	【注意】实践证明 大部分问题跟存储卡有关，小部分跟电源线有关

本车记录仪说明书所提供信息仅供参考，用户在使用过程中请以实物样机为准。若因使用本产品而导致罚款或交通意外，本公司不承担任何责任。

USER MANUAL

8. Reversing visual function
First, you must connect the dvr with car charger, rear-view camera connect the reversing lights. Insert the car charger, machine will automatically start recording status, screen switch R position in the recording mode automatically switches to the rear-view camera, display reverse image. After reversing visual machine automatically return to video mode.
Reminder: Please test the rearview camera is normal before installation.

9. Parking monitor(To achieve unattended surveillance video)
To achieve this function must be connected to the machine in the case of electricity, in the main menu to open the motion detection and parking monitoring function, in the standby state of the vehicle under vibration or moving objects in front, the recorder according to G-sensor to sense automatically start the machine and automatically locks the video for 30 seconds, and automatically save the video file, the video 30 seconds after 5 seconds without the operation will automatically shut down.
【note】 This function is only used when stopping. Please turn off the motion detection and stop monitoring function during normal driving.

FAQ	
Machine appears "file error" message	Settings menu -> Restore factory settings and format the memory card, the general problem is TF card
The screen appears horizontal stripes interference	Please select the correct power supply frequency 50HZ(PAL)
How to properly turn on the 24-hour parking monitoring function	While in normal driving, please do not open it, it is easily lead to automatic shutdown or crash, after parking is required to open, configure the buck line or mobile power please
Night shooting screen is not clear enough	Recorder shooting depends on the outside strong light source (such as streetlights or car light)
The machine always reverts to the default date and time	Shutdown in the first case full of electricity, you can use car charger or mobile power supply to add power (Turn off motion detection / Turn on the loop recording function) With a certain choice of their own genuine card C10 high-speed card
what is the reason for video file leak seconds	Please turn off the parking monitoring function first/Ambient temperature exceeds 70 °c will cause automatic shutdown
Why during recording, the machine automatically shut down suddenly	Most of the problems sources from the memory card, a small part cause of power/cord
【Note】 Practice proof	

The information provided in this manual is for reference only. Please prevail in kind (some special features depend on different models) . All rights reserved.