

L6-4k防抖加6侦探二维码执法仪中英文书 240419改

82.00

120.00



使用说明书

使用本产品前，请仔细阅读使用说明书
说明书仅供参考，具体操作以实物为准

一、产品结构

产品说明



- | | |
|-----------|-----------------|
| 1.电源键 | 10.显示屏 |
| 2.返回键 | 11.肩夹扣 |
| 3.OK键、确认键 | 12.喇叭 |
| 4.菜单键 | 13.红外灯 |
| 5.向上选择键 | 14.摄像头 |
| 6.向下选择键 | 15.爆闪灯 |
| 7.录音功能键 | 16.USB数据接口，充电接口 |
| 8.拍照功能键 | 17.复位键孔 |
| 9.录像功能键 | 18.TF卡槽 |

二、按键及接口功能介绍

- 电源键:** 长按开机、长按关机。短按息屏。
- 返回键:** 短按查看TF卡内容，再次短按退出。
- OK键、确认键:** 进入菜单状态下短按为“OK键”进入查看TF卡内容为“OK键”
- 菜单键:** 短按进入菜单界面,再次短按退出菜单。
- 上键:** 进入菜单状态短按向上选择键。
- 下键:** 进入菜单状态短按向下选择键。长按下键 进入WIFI界面，再次长按退出WIFI。
- 录音键:** 插入TF卡短按进入录音状态，再次短按退出录音功能。
- 拍照键:** 短按拍照 (长按爆闪灯及警报声) (再次长按退出爆闪灯及警报声)
- 录像键:** 插入TF卡短按进入录像功能，再次短按退出录像功能。

10.USB数据接口:

- 接口类型: Type-C
- 用于连接电源给机器充电或提供工作电源,
- 用于连接PC端可进行实时画面,
- U盘模式可查看相册及视频文件。

11.复位孔:

当机器出现花屏,异常死机等情况时,用针状物品类短戳一下重启。

12.TF卡槽:

存储卡插槽

三、基本操作说明

USB 模式

设备使用 USB 数据与电脑连接,设备自动开机后屏幕显示 ‘存储器/PC

摄像/视频模式’ 三个选项;

存储器: 在此模式下可进行视频文件或者照片文件的存取与查看;

PC 摄像: 在此模式下可用于电脑摄像头进行使用;

视频模式: 仅用于电脑给设备供电。

四、产品参数与规格

镜头	固定镜头, 130 度角
TFT 显示屏	2.0 寸彩色显示屏 (320*240)
录像分辨率	3840x2160P、2560x1440P、1920x1080P
录像文件格式	AVI
拍照录像画质	VGA-40M
移动侦测	关、开
图片设置	开/关
照片格式	JPG
循环录像	10分钟
曝光补偿	-2.0 - +2.0
录音文件格式	WAV
时间标志	关、开
自动关机	关、1分钟、3分钟、5分钟、10分钟
交流频率	50Hz、60Hz
屏幕保护	开关
语言	英、简体中、繁体中、日、韩、俄、法、德、捷克、葡萄牙、波兰、荷兰、土耳其、泰
工作湿度	20℃
工作温度	65℃
供电	USB:5V 电池:3.6V

待机	43.6uA
待机电流	3.7V
低电提示	3.49V
电源功耗	USB5V:≤400mA 电池 3.7V:≤2.0W
内存卡	TF 卡, 最大支持 128G

注意:本产品保留设计和规格更改权恕不另行通知。

APP 下载与安装:

扫描下方二维码进行APP下载安装



(WIFI可选)

长按机器右键 , 开启WIFI界面, 再按一下关闭WIFI

SSID:L6开头
密码: 12345678

Product structure

Product description



- | | |
|----------------------------------|--|
| 1. Power button | 10. Display screen |
| 2. Return key | 11. Shoulder clip buckle |
| 3.OK key, confirm key | 12. Horn |
| 4. Menu keys | 13. Infrared light |
| 5. Up selection key | 14. Camera |
| 6. Down selection key | 15. Flash lights |
| 7. Recording function key | 16. USB data interface, charging interface |
| 8. Photography function building | 17. Reset Keyhole |
| 9. Recording function key | 18. TF card residue |

Button and interface function introduction

- Power button:** Long press to turn on and long press to turn off. Short press to rest the screen.
- Return key:** Short press to view TF card content, then short press again to exit.
- OK key and confirm key:** Short press the "OK key" when entering the menu state Enter the "OK key" to view the content of the TF card
- Menu keys:** Short press to enter the menu interface. Short press again to exit the menu.
- Up key:** Short press the up selection key to enter the menu state.
- Down key:** Short press the down selection key to enter the menu state. Long press the key to enter the WIFI interface, and long press again to exit WIFI.
- Recording button:** Insert the TF card and short press to enter the recording mode, then short press again to exit the recording function.
- Photo button:** Short press to take a photo (Long press the flashing light and alarm sound) (Press and hold again to exit the flashing light and alarm sound)
- Video recording button:** Insert a TF card and short press to enter the recording function, then short press again to exit the recording function.

10. USB data interface:

- Interface type: Type-C
- Used to connect the power supply to charge the machine or provide working power,
- Used to connect to the PC for real-time display,
- In USB mode, you can view photo albums and video files.

11. Reset hole:

When the machine experiences screen flicker, abnormal crashes, etc., use a needle like object to briefly poke and restart.

12. TF card slot:

Memory card slot

Basic operating instruction

USB mode

The device uses USB data to connect to the computer. After the device starts up automatically, the screen displays three options of "memory /PC camera/video mode" :

Memory: In this mode, video files or photos can be accessed and viewed;

PC camera: In this mode can be used for computer camera;

Video mode: Used only by the computer to power the device.

Product parameters and specifications

lens	Fixed lens, 130 degree Angle
TFT display	2.0 "color display (320*240)
Video resolution	3840x2160P, 2560x1440P, 1920x1080P
Video file format	AVI
Photo and video quality	VGA-40M
Motion detection	Close and open
Picture Settings	Close and open
Photo format	JPG
Loop video	10 minutes
Exposure compensation	-2.0 -- +2.0
Recording file format	WAV
Time mark	Close and open
Automatic shutdown	Off, 1 minute, 3 minutes, 5 minutes, 10 minutes
Ac. frequency	50Hz, 60Hz
screen saver	Close and open
language	English, Simplified Chinese, Traditional Chinese, Japanese, Korean, Russian, French, German, Czech, Portuguese, Polish, Dutch, Turkish, Thai
Working humidity	20 °C
Operating temperature	65 °C
Power supply	USB:5V Battery :3.6V
standby	43.6 uA

Standby current	3.7 V
Low current warning	3.49 V
Power consumption	USB5V:≤400mA Battery 3.7V:≤2.0W
Memory card	TF card, maximum support 128G

Note: Design and specifications are subject to change without prior notice.

App download and installation:

Scan the QR code below to download and install the APP



(WIFI optional)

Long press the Right key of the product . It will open wifi interface. Then Press again to turn off Wifi

SSID:Beginning with L6
password : 12345678

Instruction manual

Please read the instructions carefully before using this product
The instruction manual is for reference only, the specific operation is subject to the actual