

Pocket Camera



Instruction Manual

I. Product structure



Note: The appearance picture is subject to the actual product

Q Product description

- 1) Record/Power button
- 2) Left arrow button
- 3) Right arrow button
- 4) Microphone
- 5) Indicator light
- 6) Horn
- 7) Front and rear steering 270 degrees
- 8) Display screen
- 9) USB port
- 10) TF card slot
- 11) Battery installation
- 12) Reset button/hole
- 13) Lens

II. Function Introduction

LCD display; touch screen function diagram; blue diagram when turned on



III. Introduction to button and interface functions

1. Record/Save button / Power button

- 1) In the video/photo recording interface, short press to start recording, and then short press again to stop recording and save.
- 2) Long press to power on/off

2 Left arrow

- 1) Long press the left arrow key to rotate the camera lens; you can position it where you want
- 2) Short press/enable follow shot; press again briefly/disable follow shot

3 Right arrow

- 1) Short press 'to switch between front and rear rotation of the lens
- 2) Long press the right arrow key to rotate the camera lens; you can position it where you want

4 microphones

It can clearly record sound in video and audio recordings

5 Indicator lights

- Blue light on/working
- Blue light flashing/video recording
- Red light on/charging
- Red light off/fully charged

6 speakers

1510 Large magnetic loudspeaker

7. Turn 270 degrees forward and backward

It can be rotated 270 degrees

8 Display screen

Color LCD touch screen

9 USB interfaces

This port can be used to connect a USB cable for charging, as well as to view or transfer files on a PC
When the camera is connected to a power source, it will automatically turn on.

10 TF card slots

The device supports a maximum of 128GB TF card. If an error is prompted or normal recording is not possible after inserting the memory card, please format the memory card in the menu settings. It is recommended to format the memory card when it is inserted for the first time
It is recommended to use a U3 memory card

11 Battery installation

18650LI-1ON 2000mAh

12 Reset button/hole

When the machine encounters issues such as a black screen or freezing, a short prick with a needle can restore it

13 camera shot

Wide-angle lens with a 90-degree view, capable of flipping up and down by 90 degrees

IV. Product Parameters and Specifications

IPS display screen	Color display screen (480*640)
resolution	2K 4K
Video file format	MP4
Photo format	JPG
loop recording	1 minute. 3 minutes. 5 minutes. 10 minutes Close
debounce	Close, open
video pre-recording	Close, open
Exposure compensation	3.0+ - 0.5 + 0.0 - 0.5 - -3.0
white balance	Automatic, Daylight, Cloudy, Tungsten Lamp, Fluorescent Lamp
Color	Normal, black and white, brown, warm tones, cool tones
ISO	Automatic 100 200 400 800 1600 3200
WDR	Close, open
Video audio	Close, open
Video volume	1, 2, 3, 4, 5, 6, 7, 8
Denoising of	Close, open

audio recording	
Time watermark	Close, open
motion detection	Close, open
Time-lapse video	Off, 5s, 10s, 15s, 30s
light metering	Average metering, center metering, spot metering
Video/photo indicator light	Close, open
prompt tone	Close. Low. Medium high
Photographing resolution	2m, 3m, 5m, 8m, 10m, 12m - 52m
Shutter speed	Automatic, 1/30s, 1s, 2s, 5s, 10s
Countdown	Off, 3s, 5s, 10s
Light source frequency	50 HZ 60 HZ
Auto Shutdown	Close. 1 minute. 2 minutes. 3 minutes. 5 minutes. 10 minutes
Screen Sleep	Close for 30 seconds, 1 minute, 3 minutes, 5 minutes
slow motion	22k/2x 1080p/4x 8x
Language	English, Simplified Chinese, Traditional Chinese, Japanese, Korean, Russian, French, German, Portuguese, Italian, Spanish, Thai, Polish, Malay, Indonesian, Arabic, Türkiye, Czech, Romanian, Vietnamese, Slovak, Finnish, Danish, Dutch,

	Greek, Hungarian, Hebrew
formatting	Confirm/Cancel
Default settings	Confirm/Cancel
Operating Humidity	30%
Operating Temperature	+65-20°C
power supply	USB voltage is 5V, current > 1A. The standby current of the entire USB device is <5.44mA
Electromechanical current	Battery standby current: <39.1uA
Low battery warning	3.6v
Power consumption	BAT3.7V/<262mA/K0.97w/JUSB 5V/s637mA/K3.68W
Memory card	TF card, supporting up to 128G

IV. Gesture function

	The person makes this gesture in front of the camera lens, and the camera follows the person. It stops following after 10 seconds away from the lens, and the lens rotation will automatically correct
	When the person makes this gesture, the camera stops following



For wifi products, please scan the QR code to download the APP
SSID; starts with Q
Password; 88888888
On the screen, swipe down from the top to enter the menu and turn on WiFi

Pocket Camera



Instruction Manual

一、产品结构



注：外形图片已实物为准

Q 产品说明

- 1)录像/电源键 2)向左键 3)向右键 4)麦克风 5)指示灯
6)喇叭 7)前后转向 270 度 8)显示屏 9)USB 接口
10)TF 卡槽 11)电池安装 12)复位键/孔 13)镜头

二、功能介绍

液晶显示；触摸屏功能图； 打开时 蓝色图



三、按键及接口功能介绍

1 录像/保存键 /电源键

- 1)在录像/拍照界面 短按开始录像，再短按停止录像+保存。
2)长按开机/关机

2 向左键

- 1) 长按向左键旋转镜头；可以定位你想要的位置

- 2) 短按/打开跟拍；再次短按/关闭跟拍

3 向右键

- 1) 短按 一键切换镜头前后旋转
2) 长按向右键旋转镜头；可以定位你想要的位置

4 麦克风

可以在视频和音频，录制中清晰地记录声音

5 指示灯

- 蓝灯亮/工作
蓝灯一闪一闪/录像
红灯亮/充电
红灯灭/充满

6 喇叭

1510 大磁喇叭

7 前后转向 270 度

可以旋转 270 度

8 显示屏

彩色液晶显示触屏

9 USB 接口

该端口可用于连接 USB 线进行充电以及在 PC 上查看或传输文件。
当相机连接电源时，相机会自动开机。

10 TF 卡槽

设备最大支持 128GTF 卡，如果内存卡插入后提示 错误或者不能正常录制，请在菜单设置中 格式化内存卡 建议首次插入的时候格式化内存卡
建议用 U3 内存卡

11 电池安装

18650LI-10N 2000 毫安

12 复位键/孔

当机器出现黑屏死机等情况时，用针短戳一下可重新恢复

13 镜头

大广角 90 度 镜头上下翻转 90 度

三、产品参数与规格

IPS 显示屏	彩色显示屏(480*640)
分辨率	2K 4K
录像文件格式	MP4
照片格式	JPG
循环录像	1 分钟.3 分钟.5 分钟.10 分钟.关
防抖	关闭、开启

视频预览	关闭、开启
曝光补偿	3.0+ - 0.5 + 0.0 - 0.5 - - 3.0
白平衡	自动 日光 阴天 钨丝灯 荧光灯
色彩	正常 黑白 棕褐色 暖色调 冷色调
ISO	自动 100 200 400 800 1600 3200
WDR	关闭 开启
录影音频	关闭 开启
录影音量	1、2、3、4、5、6、7、8
录音去噪	关闭、开启
时间水印	关闭、开启
移动侦测	关闭、开启
延时录影	关闭、5s、10s、15s、30s
测光	平均测光.中央测光.点测光.
录像/拍照指示灯	关闭、开启
提示音	关闭.低.中.高
拍照分辨率	2m、3m、5m、8m、10m、12m - 52m
快门速度	自动、1/30s、1s、2s、5s、10s
倒计时	关闭、3s、5s、10s
光源频率	50 HZ 60 HZ
自动关机	关闭.1 分钟.2 分钟.3 分钟.5 分钟.10 分钟
屏幕休眠	关闭 30s 1 分钟 3 分钟 5 分钟
慢动作	22k/2x 1080p/4x 8x
语言	英、简体中、繁体中、日、韩、俄、法、德、葡萄牙、意大利、西班牙、泰、波兰、马来、印尼、阿拉伯、土耳其、捷克、罗马尼亚、越南、斯洛伐克、芬兰、丹麦、荷兰、希腊、匈牙利、希伯来

格式化	确认/取消
默认设置	确认/取消
工作湿度	30%
工作温度	+ 65-20°C
供电	USB 电压 5V，电流>1AUSB 整机待机电流:<5.44mA
机电流	电池待机电流:<39.1uA
低电提示	3.6v
电源功耗	BAT3.7V/<262mA/K0.97w/JUSB5V/s6 37mA/K3.68W
内存卡	TF 卡，最大支持 128G

四、手势功能

	人物在相机镜头正面做出此手势相机跟随人物，离开镜头 10 秒后停止跟随，镜头旋转会自动矫正
	人物做出此手势相机停止跟随



wifi 产品请扫码下载 APP

SSID;Q 开头

密码;88888888

屏幕上 从上往下滑进入菜单打开 wifi