



记录仪产品说明书


独家四路摄像头

一、产品规格说明

| | |
|--------------|---|
| DDR | 内置64M |
| FLASH | 8M SPI norflash |
| 显示屏 | 3.0英寸IPS高清屏 |
| 显示屏分辨率 | 800X480 像素 |
| 外接端口 | Tpcc-USB 5V/2A电源接口 最大支持64G Class10 TF卡 2.5mm三节数字后录摄像头接口 |
| 扬声器 | 8欧1瓦单声道15*10mm扬声器 |
| MIC | 4015标准全指向麦克风 |
| 功能特性： | |
| 前置摄像头 | 1920x1080P |
| 车内摄像头(可选) | 1280x720P |
| 后视镜摄像头 | 6米线长/2.5mm接口 |
| 拍照 | 支持 |
| 镜头旋转 | 支持手动调整 |
| 动态范围调节 | 支持 |
| HDR | 支持 |
| 倒车全屏 | 支持 |
| 视频格式 | AVI |
| 图片格式 | JPG |
| 存储压缩方式 | H.264 |
| 电池类型 | 聚合物锂电池 |
| 语言支持 | 支持多国语言 |
| 重力感应 | 支持 |

| | |
|--------------|------------|
| 移动侦测 | 支持 |
| 延时关机 | 支持 |
| 循环录像 | 支持,不覆盖 |
| 录音功能 | 支持 |
| 夜视补光灯 | 支持(手动开启) |
| 停车监控 | 支持 |
| 前置摄像头画质 | 1920x1080P |
| 车内摄像头画质 | HD1280x720 |
| 拍照分辨率 | 最高支持3M |
| 工作环境： | |
| 操作温度 | -40℃~70℃ |
| 操作湿度 | 15-65%RH |
| 存储温度 | -40℃~70℃ |

二、按键功能介绍(图片仅供参考,以实物为准)



- 1) 电源键, 短按息屏
- 2) 确认键 OK键
- 3) 菜单键
- 4) 下翻键
- 5) 上翻键, 长按打开夜视灯
- 6) 显示屏
- 7) 车内摄像头
- 8) 夜视灯
- 9) 支架卡口
- 10) 复位键
- 11) 后视镜摄像头 (可选)
- 12) TF卡槽
- 13) 电源接口
- 14) 车前摄像头

录像时长按【M】进入菜单设置, 具体项目如下:

| 记录仪录像菜单 | | | |
|---------|------|-------------------|------------------------|
| 1 | 分辨率 | 1080P FHD/720P | |
| 2 | 循环录影 | 关/1分钟/2分钟/3分钟/5分钟 | |
| 3 | 曝光补偿 | -3,-2,-1,0,1,2,3 | |
| 4 | 移动检测 | 开关 | 待机状态下有物体移动会自动开机录制 |
| 5 | 录音音频 | 开关 | 打开或关闭同步录音 |
| 6 | 日期标签 | 开关 | |
| 7 | 重力感应 | 关/2G/4G/8G | 剧烈晃动或碰撞后, 视频自动保存并不能被覆盖 |
| 8 | 停车监控 | 关/开 | 无人值守监控录像 |
| 9 | 日期时间 | 调整年/月/日/时/分/秒 | |
| 10 | 自动关机 | 关/1分钟/3分钟 | |
| 11 | 按键声音 | 关/开 | |
| 12 | 语言设置 | 简体中文等多国语言 | 选择语言 |

| | | | |
|----|------|----------------|--------|
| 13 | 光源频率 | 50HZ/60HZ | 光源频率选择 |
| 14 | 格式化 | 确认/取消 | 格式化TF卡 |
| 15 | 屏幕保护 | 关/3分钟/5分钟/10分钟 | |
| 16 | 默认设置 | 确认/取消 | |
| 17 | 版本 | 机器软件版本号 | |

拍照模式下长按【M】进入拍照菜单设置, 具体项目如下:

| | | |
|---|------|---------------------|
| 1 | 拍摄方式 | 单拍/2秒定时/5秒定时/10秒定时 |
| 2 | 分辨率 | 2M/3M/5M/8M/10M/12M |
| 3 | 连拍 | 开关 |
| 4 | 图像质量 | 优质/标准/经济 |
| 5 | 锐度 | 强烈/标准/柔和 |
| 6 | 白平衡 | 自动/日光/阴天/钨丝灯/荧光灯 |
| 7 | ISO | 自动/100/200 |
| 8 | 曝光补偿 | -3,-2,-1,0,1,2,3 |
| 9 | 日期标签 | 关/日期时间 |

【C】为开关机电源键, 短按息屏。

【M】为菜单, 长按查看菜单, 长按进入拍照界面按确认键拍照。

【▲】为上翻键, 长按打开夜视灯。

【▼】为下翻键, 短按切换镜头画面。

【OK】为确认键, 菜单界面短按为确认, 录像界面短按为录像开启/停止切换功能。

后视镜摄像头介绍 (若有此配置)

在录像状态下, 后视镜摄像头镜头插入AVINR, 屏幕会有一小块区域显示为后视镜画面, 若已识别后视镜摄像头, 短按【OK】暂停录像后, 长按【▼】可在车前摄像头、后视镜

摄像头两种显示画面之间切换, 当使用侧挡时, 自动全屏显示后视镜摄像头画面。

复位键【RESET】
如记录仪发生死机及意外操作不正常故障, 短按【RESET】可进入POWER OFF状态, 再短按【OK】重启机器。

安装说明

1. 请先测试好后视镜摄像头正常后再进行安装 (若有后视镜摄像头, 没有的可忽略)。
2. 关闭汽车发动机。
3. 将TF卡插入记录仪卡槽中。
【注意】请使用高速TF卡 (Class10以上), 容量不小于4GB, TF卡最大支持64GB。
4. 将记录仪通过支架固定于汽车前挡风玻璃上。
5. 将车载充电器插入汽车点烟器中。
6. 将前置摄像头安装在车辆后部, 安装时注意上下方向, 布线可沿车辆棚边缘埋线铺设。
1.【注意】后置摄像头有两种安装方法:
A. 吸附于汽车后玻璃上方, 可自行动手安装 (无法实现倒车可视功能, 只能实现倒车可视功能)。
B. 找专业安装人员安装于车辆上方, 同时摄像头需要连接倒车灯电源 (可实现倒车可视功能)。
2. 调整镜头位置, 确保最佳拍摄角度。
3. 发动引擎, 检查机器是否正常运行。

功能介绍

1. 使用自动记录功能
启动汽车发动机, 记录仪自动启动并开启记录功能。
关闭汽车发动机, 记录仪自动保存记录内容并关机, 记录的视频片段保存于TF卡上。当TF卡存满后, 记录仪将优先覆盖最早录制的影像。
【注意】
a. 记录的时间段可自行在菜单中设置, 范围为关闭1/1/2/3分钟4档。
b. 记录仪分别保存于TF卡内DCIMA与DCIMB文件夹中 (若有车内摄像头或者后视镜摄像头)。
2. 使用拍照功能
在开机状态下, 短按【OK】键停止录像, 短按【M】键进入拍照模式, 短按OK键即可拍照。如常切换回录像模式, 短按【▲】键即可。
3. 使用移动侦测功能 (运动检测)

4. 重力感应功能
本机内置重力感应器(G-sensor), 如果发生严重车辆碰撞, 记录仪会锁定事故发生时的前5秒和后10秒的影像资料, 同时显示屏上方显示锁定的图标; 被锁定的影像会另存为一个特殊文件, 这个文件不会被循环覆盖。
【提示】重力感应器 (G-sensor) 支持灵敏度调节, 可根据实际需要设置在设置菜单中自行更改设置。

5. 一键锁定功能
本机具备一键锁定功能, 可将需要保留的影像锁定而不会被循环覆盖。在录像模式中, 短按【M】键记录仪会将当前整段的视频影像锁定。

6. 日期及时间设定
录像时长按【M】键进入菜单设置, 找到日期/时间菜单, 短按OK键进入, 设置正确后再按【OK】键保存, 最后短按【M】键退出菜单设置。
【注意】为了有效记录和取证, 在使用本机前请立即设置正确的日期和时间。

7. 文件回放
回放模式下按【OK】键回放。如需退出回放模式, 再次短按【M】键。

8. 倒车可视功能 (后视镜摄像头为可选配件)
首先, 必须车充连接好记录仪, 拉线摄像头上黑红线连接倒车灯, 插车充机器会自动启动录像状态, 在录像模式下切换档屏幕会自动切换到后视镜镜头, 显示倒车影像。结束倒车后可视机器自动返回录像模式。
提醒: 请先测试好后视镜摄像头正常后再进行安装。

9. 停车监控功能 (实现无人值守监控录像)
实现这个功能必须在本机连接带电的情况下, 在主菜单中打开运动检测和停车监控功能, 在待机状态下车辆受到震动或者前方有物体移动时, 记录仪可根据重力感应模块G-SENSOR来感应, 自动启动机器并自动录像30秒, 且自动保存录像文件。

常见问题

| | |
|------------------|--|
| 车子出现“档案错误”的提示 | 设置菜单->恢复出厂设置并格式化内存卡, 一般是TF卡的问题 |
| 画面出现横条纹干扰 | 请选择正确的供电频率50HZ(PAL) |
| 如何正确开启24小时停车监控功能 | 正常使用, 请不要开启, 容易造成自动关机或死机停车后才需要开启, 请配置降压或移动电源 |

| | |
|--------------------|--|
| 夜间拍摄的画面不够清晰 | 记录仪拍摄依赖于外界较强的光源 (比如路灯车灯), 行业亦是如此 |
| 机器总是恢复到默认日期和时间 | 关机的情况下先充满电, 可以用车充或者移动电源补充电量 |
| 录像文件出现覆盖, 是什么原因 | 请先关闭移动侦测功能/打开循环录像功能) 自行配卡的一定选用正品10高速卡。 |
| 为何录制过程中, 机器一下子自动关机 | 请先关闭停车监控功能/使用环境的温度超过70℃将会造成自动关机 |
| 【注意】实践证明 | 大部分问题跟停车线卡有关, 小部分跟电源线有关自行更改设置。 |

本行车记录仪说明书所提供信息仅供参考, 用户在使用过程中请以实物样机为准。若因使用本产品而导致罚款或交通意外, 本公司不承担任何责任。

一、Product Specification

| | |
|--------------------------|---|
| DDR | Built-in 64M |
| FLASH | 8M SPI norflash |
| Display Screen | 3.0 inch IPS HD screen |
| LCD resolution | 800X480 pixels |
| 外接端口 | Tpcc-USB 5V/2A power interface Max support 64G Class10 TF card 2.5mm digital 720P rear view lens port |
| Speaker | Monophonic 15*10mm speaker |
| MIC | 4015 Standard Omnidirectional Microphone |
| Features: | |
| Front camera | 1920x1080P |
| Inside camera (optional) | 1280x720P |
| Rear camera | 6M cable/2.5mm port |
| Photo | Support |
| Lens rotates | Adjust manually |
| WDR | Support |
| HDR | Support |
| Reversing visual | Support |
| Video format | AVI |
| Image format | JPG |
| Compression format | H.264 |
| Battery | Polymer battery |
| Language | support multi-language |
| G-sensor | Support |

| | |
|-----------------------------|------------------------------|
| Motion Detection | Support |
| Delay shutdown | Support |
| Loop recording | Support, Do not leak seconds |
| Sound record | Support |
| Fill light for night vision | Support(Open manually) |
| Parking monitoring | Support |
| Front camera | 1920x1080P |
| In-car camera resolution | HD1280x720 |
| Camera resolution | Max support 3M |
| Working Environment | |
| Operating temperature | -40℃~70℃ |
| Operating humidity | 15-65%RH |
| Storage temperature | -40℃~70℃ |

二、Key Features (picture for reference only, mainly in kind)



- 1) Power button, short press to stop the screen
- 2) Confirm key OK key
- 3) Menu keys
- 4) Flip down key
- 5) Flip up button, long press to turn on night vision light
- 6) Display screen
- 7) In car camera
- 8) Night vision lamp
- 9) Bracket clamp
- 10) Reset key
- 11) Rear view camera (optional)
- 12) TF card slot
- 13) Power interface
- 14) Front camera

In video mode ,long press 【M】 to enter video menu settings as follows:

| Recorder Menu | | | |
|---------------|-----------------------|--|--|
| 1 | Resolution | 1080P FHD/720P | |
| 2 | Loop recording | Off/1minutes/2minutes/3minutes/5minutes | |
| 3 | Exposure compensation | -3,-2,-1,0,1,2,3 | |
| 4 | Movement detection | on/ off | In standby mode, it will automatically record while a objective moves |
| 5 | Sound record | on/ off | Turn on/off sound record |
| 6 | Time stamp | on/ off | |
| 7 | G-sensor | Off/2G/4G/8G | When car occur collision/accident, it will lock current video and can't be covered |
| 8 | Parking monitor | on/ off | unattended surveillance |
| 9 | Date/time | Adjustment Years months date/hours/Minutes/seconds | |
| 10 | Automatic shut-down | Off/1minutes/3minutes | |
| 11 | keypad tone | on/ off | |
| 12 | OSD language | Support multilingual | Choose a language |

Rear view lens (optional)
In case of video recording, 4 pin plug of rear view lens insert AV-in hole of device, there's a rear view image in top right of the screen, that means connected successfully, short press OK button to pause, long press 【▼】button to switch front-rear view image, When hang up "R" gear, it will show full image of rear view

Note: This device can only support dual cameras to video record at the same time instead of 3 channels camera, that is front-inside camera or front-rear camera, if installed a rearview

| | | | |
|----|------------------------|-----------------------------------|-----------------------------------|
| 13 | Light source frequency | 50HZ/60HZ | Choose the Light source frequency |
| 14 | format | Confirm/cancel | format TF card |
| 15 | Screen saver | Off/3minutes/5minutes / 10minutes | |
| 16 | Default setting | Confirm/ cancel | |
| 17 | version | Machine software version number | |

In photo mode ,long press 【M】 to enter photo menu settings as follows:

| | | |
|---|-----------------------|--|
| 1 | Shooting method | Single shooting/2 seconds timer / 5 seconds timer / 10 seconds timer |
| 2 | Resolution | 2M/3M/5M/8M/10M/12M |
| 3 | Continuous shooting | on/ off |
| 4 | Picture quality | High quality/standard/economy |
| 5 | Acutance | Strong/standard/soft |
| 6 | White balance | Automatic/sunlight/cloudy/tungsten lamp/fluorescent lamp |
| 7 | ISO | Automatic/100/200 |
| 8 | Exposure compensation | -3,-2,-1,0,1,2,3 |
| 9 | Time stamp | Off/ Date |

1. Please test the rear view camera firstly, if it works well then install (package without rear view lens can be ignored).
2. Turn off the car engine.
3. The TF card insert the recorder slot.
【Note】Please use the high-speed TF card (Class10 above), capacity of not less than 4GB, TF card maximum support 64GB.
4. The recorder via a bracket fixed to the front windshield of the car.
5. Insert the car charger into the car cigarette lighter.
【Note】When wiring, extend the charging line along the edge of the car door frame and capped under the car laying.
6. Install the rear camera at the rear of the vehicle, and pay attention to the up and down direction. Wiring can be buried along the edge of the car roof laying. 【Note】There are two ways to install the rear camera:
A. Adsobered on the glass above and behind the car, hands-on self-installation (Reversing visual function can not be achieved, only real-time recording rear video).
B. To find a professional installation staff installed in the license plate above the camera at the same time need to connect the power reversing lights (Reversing visual function can be achieved).
7. Adjust the lens position to ensure the best viewing angle.
8. Start the engine and check that the machine is operating properly.

Installation Notes

1. Use the automatic recording function.
Start the car engine, the recorder automatically starts to open the recording function. Close the car engine. The recorder automatically saves the contents of the log and shuts down, recorded video segments are stored on the TF card. When the TF card is full, the recorder will overwrite the oldest recorded image preferentially.
【Note】
a. Time segment of record can be set 1/2/3 minutes in the menu.
b. The video individually saved in the folder name "DCIMA" and "DCIMB" in TF card (package include rear view lens).

3. Use motion detection
In standby mode, enter the menu screen open the motion detection mode. When the lens is sensitive to the peripheral area of a moving object, the state machine into the camera, recording 30 seconds after the system stops recording. To exit the motion detection mode, in standby mode to enter the menu screen close motion detection mode.

camera and choose front-inside view mode, it will automatically indicate full image of car reversing visual when you hang up "R" gear, but won't affect front-inside video record, also will automatically switch back front-inside view after cancel "R" gear.
As for system update to support 3 channels camera a video record at the same time, please prevail in kind and we're sorry for no further notice.

Reset key【RESET】
If the recorder crashes and accidental operation is not a normal fault, press 【RESET】 to shutdown the device, then press 【OK】 to reboot the device.

5. The device has a key lock feature that will need to retain an image without being locked loop overwritten. In the video mode, short press 【M】 key logger will then lock the entire video image.

6. In shooting mode, Press the 【M】 key to enter the menu setting, find the date /time menu, short press the 【OK】 button to confirm and return to the setup menu settings, press the 【M】 key to exit the menu setting. 【note】 In order to effectively record the date and time traffic safety accident forensics, before using the menu setting.

7. File playback
In the playback mode, press the (OK) key to play back. To exit playback mode, press MODE button again.

8. Reversing visual function
First, you must connect the dvr with car charger, rear-view camera connect the reversing lights. Insert the car charger, machine will automatically start recording status, screen switch R position in the recording mode automatically switches to the rear-view camera, display reverse image. After reversing visual machine automatically return to video mode.
Reminder: Please test the rearview camera is normal before installation.

9. Parking monitor(To achieve unattended surveillance video)
To achieve this function must be connected to the machine in the case of electricity in the main menu to open the motion detection and parking monitoring function, in the standby state of the vehicle under vibration or moving objects in front, the recorder according to G-sensor to sense automatically start the machine and automatically locks the video for 30 seconds, and automatically save the video file, the video 30 seconds after 5 seconds without the operation will automatically shut down.
【note】 This function is only used when stopping. Please turn off the motion detection and stop monitoring function during normal driving.

FAQ

| | |
|---|--|
| Machine appears "file error" message | Settings menu -> Restore factory settings and format the memory card, the general problem is TF card |
| The screen appears horizontal stripes interference | Please select the correct power supply frequency 50HZ(PAL) |
| How to properly turn on the 24-hour parking monitoring function | While in normal driving, please do not open it, it easily lead to automatic shutdown or crash after parking is required to open, configure the back line or mobile power phase |

| | |
|--|--|
| Night shooting screen is not clear enough | Recorder shooting depends on the outside strong light source (such as streetlights or car light) |
| The machine always reverts to the default date and time | Shutdown in the first case full of electricity, you can use car charger or mobile power supply to add power |
| what is the reason for video file leak seconds | (Turn off motion detection, Turn on the loop recording function) With a certain choice of their own genuine card C10 high speed card |
| Why during recording, the machine automatically shut down suddenly | Please turn off the parking monitoring function first/Ambient temperature exceeds 70 °C will cause automatic shutdown |
| 【Note】Practice proof | Most of the problems sources from the memory card, a small part causes of power cord |

The information provided in this manual is for reference only. Please prevail in kind (some special features depend on different models). All rights reserved.