

# -L9 2K加6侦探二维码执法仪中英文说明书(82x120)

82.00

## 执法仪



### 使用说明书

使用本产品前，请仔细阅读使用说明书  
说明书仅供参考，具体操作以实物为准

#### 一、产品结构

产品说明



- |                   |               |                   |
|-------------------|---------------|-------------------|
| 1) 爆闪灯            | 2) 摄像头        | 3) 红外灯            |
| 4) 喇叭             | 5) 肩夹扣        | 6) 显示屏            |
| 7) 上键/长按打开夜视或关闭夜视 | 8) 菜单键        | 9) 下键/长按打开或关闭WIFI |
| 10) 录像模式键         | 11) 拍照模式键     | 12) 录音开关键         |
| 13) OK确认键         | 14) 返回键/回放模式键 | 15) 电源键           |
| 16) USB 数据接口      | 17) 复位孔       | 18) TF 卡槽         |

#### 二、按键及接口功能介绍

##### 7. 上键

向上选择键：长按打开夜视，再次长按退出夜视。

##### 8. 菜单键

短按进入设置菜单，再次短按退出菜单。

##### 9. 下键

向下选择键：长按打开WIFI，短按返回，3S后，后台全部退回

##### 10. 录像模式键

短按进入录像模式，再次短按即可进行录像。

##### 11. 拍照模式键

短按进入拍照模式，再次短按即可拍照。

##### 12. 录音开/关键

短按打开录音，长按退出录音

##### 13. 菜单状态下短按为“OK键”；

##### 14. 返回键/回放模式键

短按进入返回模式；再次短按进入文件查看模式。

##### 1. 爆闪灯操作方法

第一次长按拍照模式键打开爆闪灯+声音

第二次长按拍照模式吉安，只打开爆闪灯无声音

第三次长按关闭

#### 15. 电源键

1) 短按可熄屏，再次短按可亮起；

2) 长按可开/关机。

#### 16. USB 数据接口

1) 接口类型：Type-C

2) 用于连接外接电源给电池充电或提供工作电源。

3) 用于连接 PC 端可进行实时画面；

4) U 盘模式可查看相册文件；

#### 18. 复位孔

当机器出现花屏、异常死机等情况时，用针孔状的东西短戳一下可重新启动。

#### 12. TF 卡槽

存储卡插槽

### 三、基本操作说明

#### USB 模式

设备使用 USB 数据与电脑连接，设备自动开机后屏幕显示“存储器/PC 摄像/视频模式”三个选项；

**存储器：**在此模式下可进行视频文件或者照片文件的存取与查看；

**PC 摄像：**在此模式下可用于电脑摄像头进行使用；

**视频模式：**仅用于电脑给设备供电。

### 四、产品参数与规格

镜头	固定镜头，130 度角
TFT 显示屏	2.0 寸彩色显示屏 (320*240)
录像分辨率	3840x2160P、2560x1440P、1920x1080P
录像文件格式	AVI
拍照录像画质	VGA-40M
移动侦测	关、开
图片设置	开/关
照片格式	JPG
循环录像	10分钟
曝光补偿	-2.0 -- +2.0
录音文件格式	WAV
时间标志	关、开
自动关机	关、1分钟、3分钟、5分钟、1分钟
交流频率	50Hz、60Hz

#### APP 下载与安装：

扫描下方二维码进行APP下载安装



(WIFI可选)

长按机器右键▶，开启WiFi界面，再按一下关闭WiFi

SSID:L9-Z1开关

密码：12345678

屏幕保护	开关
语言	英、简体中、繁体中、日、韩、俄、法、德、捷克、葡萄牙、波兰、荷兰、土耳其、泰
工作湿度	20℃
工作温度	65℃
供电	USB:5V 电池:3.6V
待机	43.6uA
待机电流	3.7V
低电提示	3.49V
电源功耗	USB5V:≤400mA 电池 3.7V:≤2.0W
内存卡	TF 卡，最大支持 128G

注意:本产品保留设计和规格更改权恕不另行通知。

## Law enforcement instrument



### Instruction manual

Please read the instructions carefully before using this product  
The instruction manual is for reference only, the specific operation is subject to the actual

#### Product structure

Product description



- |   |                                  |   |
|---|----------------------------------|---|
| 1)Explosive flashing light                      | 2) Camera                        | 3) Red lights                                 |
| 4) Horn   | 5) Shoulder clip buckle          | 6) Display screen                             |
| 7) Up/Long press to turn on or off night vision | 8) Menu key                      | 9) Press and hold down to turn on or off WIFI |
| 10) Video mode key                              | 11) Photo mode key               | 12) Recording on key                          |
| 13) OK confirmation key                         | 14) Return key/playback mode key | 15) Power button                              |
| 16) USB data interface                          | 17) Reset hole                   | 18) TF card slo                               |

#### Button and interface function introduction

##### 7. Press the upper key

Up selection key: Long press to turn on night vision, and long press again to exit night vision.

##### 8. Menu key

Tap to enter the Settings menu and tap again to exit the menu.

##### 9. Press the down button

Downward selection key: Long press to open WIFI, short press to return, after 3 seconds, the background will all return

##### 10. Video Mode key

Press to enter the recording mode, and press again to record.

##### 11. Photo Mode button

Press to enter the photo mode, and press again to take a picture.

##### 12.Recording on/off key

Short press to open recording, long press to exit recording

##### 13. In the menu state, press the "OK key";

##### 14. Return key/playback mode key

Short press to enter return mode; long press to enter file viewing mode.

##### 15. Power button

1) Short press to extinguish the screen, and short press again to light up;

2) Long press to turn on/off.

##### 1. Operation method of flashing light

Press and hold the photo mode button for the first time to turn on the flashing light and sound

Press and hold the photo mode for the second time, Jian, only turn on the flashing light without any sound

Third long press to close

#### 16.USB data port

1) Interface Type: type-c

2) It is used to connect the external power supply to charge the battery or provide the working power supply.

3) It is used to connect the PC terminal for real-time screen;

4) You can view album files in U disk mode;

#### 17. Reset the hole

When the machine appears flower screen, abnormal crash, etc., with a pinhole - like thing short poke can restart.

#### 18.TF card slot

Memory card slot

### Basic operating instruction

#### USB mode

The device uses USB data to connect to the computer. After the device starts up automatically, the screen displays three options of "memory /PC camera/video mode" :

Memory: In this mode, video files or photos can be accessed and viewed;

PC camera: In this mode can be used for computer camera;

Video mode: Used only by the computer to power the device.

### Product parameters and specifications

lens	Fixed lens, 180 degree Angle
TFT display	2.0 "color display (320*240)
Video resolution	3840x2160P, 2560x1440P, 1920x1080P
Video file format	AVI
Photo and video quality	VGA-40M
Motion detection	Close and open
Picture Settings	Close and open
Photo format	JPG
Loop video	10 minutes
Exposure compensation	-2.0 -- +2.0
Recording file format	WAV
Time mark	Close and open

#### App download and installation:

Scan the QR code below to download and install the APP



(WIFI optional)

Long press the Right key of the product▶. It will open wifi interface. Then Press again to turn off WiFi

SSID:L9-Z1 switch  
password : 12345678

Automatic shutdown	Off, 1 minute, 3 minutes, 5 minutes, 10 minutes
Ac frequency	50Hz, 60Hz
screen saver	Close and open
language	English, Simplified Chinese, Traditional Chinese, Japanese, Korean, Russian, French, German, Czech, Portuguese, Polish, Dutch, Turkish, Thai
Working humidity	20 °C
Operating temperature	65 °C
Power supply	USB:5V Battery :3.6V
standby	43.6 uA
Standby current	3.7 V
Low current warning	3.49 V
Power consumption	USB5V:≤400mA Battery 3.7V:≤2.0W
Memory card	TF card, maximum support 128G

**Note: Design and specifications are subject to change without prior notice.**